



A  
M8 X 50  
4 PCS



B  
1 PC

# STEP 01

SECURE WOOD LEG FRAME  
TO THE SEAT CUSHION.  
SECURE WITH 4 A SCREWS.

